

# ARDEX TLT™ Niches

## Installation Guide

---

ARDEX TLT™ Niches are made of high density, closed cell foam that is 100% waterproof. These niches can be installed before or during tile installation.

### STEP 1

Determine desired location and trace your niche dimensions, including outside dimensions, onto the ARDEX TLT™ Building Panel making sure the lines are level and plumb. Cut and remove the building panel such that the ARDEX TLT™ Niche will be supported on both sides of the studs or other wall framing.

### STEP 2

Place a bead of ARDEX TLT™ 700 on the stud frame where the lip of the niche will sit. Insert the waterproof ARDEX TLT™ Niche into cut location. Use ARDEX TLT™ 700 around all stud framing and building panel seams. Use the ARDEX TLT™ Screws & Washers to fasten to the wall panels, placing these fasteners approximately 1/4" from the edges of the niche. Fasten all corners and limit fastener spacing to 12" o.c.

**Note:** The exact order of installation can vary, provided all fastening and waterproofing measures are performed properly.



tile & stone  
Installation Systems

[www.ardexamericas.com](http://www.ardexamericas.com)

BUILT BY  
**YOU**  
backed by **ARDEX**